

What does "Active System Console" actually mean in my Intel server setup, and how should I be using it?

TechRounder Help Center PDF

Live article:

<https://www.techrounder.com/help/what-does-active-system-console-actually-mean-in-my-intel-server-setup-and-how-should-i-be-using-it/>

By Vipin PG | Published August 14, 2026 | Updated August 14, 2026 | Topic: Solution | 4 min read

If you found a reference to Intel Active System Console (IASC) on an install disc, in an old manual, or on a legacy Intel Server Board like an S2600 series, here's the short version: it's dead software. Intel killed it off back in January 2020, pulled it from their download center, and never built a direct successor. So if you're wondering how you "should be using it" - the honest answer is you probably shouldn't be setting it up fresh at all.

What IASC Actually Was

IASC was a lightweight, locally-installed web app that ran directly on the server's operating system. It gave you a dashboard for basic health monitoring - fan status, voltage sensors, event logs - plus some BMC (Baseboard Management Controller) configuration options. Intel aimed it at small businesses that needed something simpler than full data center tooling. You'd install it via Start > Programs > Intel Server Management Software, then either use it locally or hit it remotely through a browser using the server's own IP address.

That last part is the key limitation: IASC shared the host's network identity. It wasn't isolated from the OS, and it couldn't do anything if the server was powered off or the OS crashed - because it depended on the OS to run in the first place.

Why It's Not Coming Back

Intel officially retired both IASC and its companion tool, Intel Multi-Server Manager, and explicitly said there's no successor planned to replace them one-for-one. The installer files aren't hosted on Intel's site anymore. If you dig one up from a third-party mirror or an old driver CD, treat it with caution - it's unsupported, unpatched, and running unmaintained software with hooks into your hardware sensors and BMC isn't something you want long-term.

What To Use Instead

Intel's own guidance is straightforward: use the Integrated BMC Web Console (sometimes called BMC EWS, for Embedded Web Server) that's already built into the server board. It's not a separate install - it's baked into the BMC firmware and does everything IASC did, plus more, because it doesn't depend on the host OS at all.

Here's how to get into it:

1. Reboot the server and press F2 during POST to enter BIOS setup.
2. Go to Server Management .
3. Scroll to BMC LAN Configuration .
4. Open User Configuration and set up an admin account - pick a user slot (2-4), set Privilege to Administrator , set User Status to Enabled , and create a username and password. Skip the anonymous user option; leave it disabled.

5. Back on the BMC LAN Configuration screen, decide how you're connecting: if you're sharing NIC 1 with the host, configure it under Baseboard LAN Configuration. If you've got a dedicated management port (recommended), configure that separately.
 6. Set IP Source to Dynamic for DHCP, or Static if you want to enter the IP, subnet mask, and gateway manually.
 7. Press F10 to save and exit.
 8. If you went DHCP, reboot back into BIOS to check the address it picked up, or check your DHCP server's lease table.
 9. From any machine on that network, open a browser and go to that IP address, then log in with the credentials you just created.
- You can also configure all of this through the Intel SysCfg utility from the EFI shell or OS, or with `ipmitool` on Linux, if you'd rather script it than click through BIOS menus.

Why This Is Actually a Better Setup, Not a Downgrade

People coming from IASC sometimes assume the BMC web console is a stripped-down replacement. It's the opposite. IASC never had:

- Power actions (remote reboot/shutdown)
- SOL or KVM launch for full remote console access
- Virtual media redirection (mounting an ISO remotely to reinstall an OS)
- Remote firmware and BIOS updates
- Access when the OS is down or the system is powered off - since the BMC runs independently on its own chip

The BMC console also gets its own IP address, isolated from the host - so you can put it on a dedicated out-of-band management VLAN and keep it off your regular network entirely, which is a real security win over IASC sharing the host's identity.

If You're Stuck on an Old Box Still Running IASC

Some legacy systems still have it installed and working. If you're maintaining one rather than replacing it, a couple of practical notes: IASC uses TCP ports 9393, 9191, and 7777 for its web service and backend IPC - if you can reach it locally but not remotely, check that these aren't blocked by a firewall in between. You'll also likely hit a browser warning ("Untrusted Connection" in Firefox, "Invalid Security Certificate" in older IE) because IASC's certificate was never signed by a public CA - that's expected, not a sign of compromise, and you just need to accept the exception to get to the login page.

Quote: Long-term, don't rebuild anything around IASC. If the board supports the Integrated BMC Web Console (any Purley-era S2600WF/BP/ST/WK or Grantley-era S2600WT/KP/TP/CW board, or the single-socket S1200SP), migrate to that instead - it's free, already on the hardware, and actively maintained as part of BMC firmware updates.