

Easy Fix for DTH Channel Not Able to Watch After Recharge

TechRounder PDF Edition

Live article: <https://www.techrounder.com/dth/easy-fix-for-dth-channel-not-able-to-watch-after-recharge/>

By Vipin PG | Published August 19, 2024 | Updated September 4, 2024 | Format: Article | 2 min read

In brief

Have you ever faced this frustrating situation? You've just recharged your DTH (Direct-to-Home) service, but your TV channels are still not working.

Have you ever faced this frustrating situation? You've just recharged your DTH (Direct-to-Home) service, but your TV channels are still not working. Don't worry! There's a simple solution that doesn't require calling customer service or waiting for hours.

The Missed Call Method

DTH companies in India have introduced a clever way to solve this problem: the missed call refresh. It's a quick and easy method to update your account and activate your channels. Here's how it works:

1. Use Your Registered Number: You must call from the mobile number that's registered with your DTH account.
2. Call the Refresh Number: Each DTH provider has a specific number for this service.
3. Give a Missed Call: Let the phone ring once, then hang up. You don't need to actually speak to anyone.
4. Wait a Few Minutes: The system recognizes your number, checks your account, and activates your channels.

Refresh Numbers for Major DTH Providers

Keep these numbers handy:

- D2h: 18001700777
- Dish TV: 18002744744
- Airtel Digital TV: 8448284708
- Tata Play: 9040590405

When Should You Use This Method?

This missed call trick is useful in several situations:

- Right after a recharge when your channels don't activate automatically
- If you see a message on your TV saying your account is inactive
- When your subscribed channels suddenly stop working

Why This Method is So Helpful

- Quick: It usually works within minutes
- Available 24/7: You can use it any time, day or night
- Free: There's no charge for this service
- User-Friendly: It's so simple, anyone can do it

How It Works Behind the Scenes

When you give a missed call:

1. The system recognizes your phone number
2. It checks your account status and recent recharges
3. If there's an activation pending, it immediately updates your account
4. Your subscription is refreshed, and channels are activated

What If It Doesn't Solve the Problem?

If the missed call method doesn't work, it might indicate a more complex issue. In this case, you may need to contact your DTH provider's customer support for further assistance.

Tips

Save these numbers in your phone under names like "D2h Refresh" or "Tata Play Activate". This way, you'll always have them handy when you need them. Remember, this simple trick can save you time and get you back to enjoying your favorite TV shows quickly. It's a great example of how technology is making our lives easier!